

1600 Totem Display Unit Assembly Instructions



- 1 Stand the main panel upright so the 4 slotted tabs are facing up then peel back the protective film about 2 inches down. Then place the black shaper over the unit.



- 2 Position the base assembly over the upright panel so the 4 tabs locate in their corresponding slots through the base.



- 3 Slide the curved locking pegs through the slots located at the far left and far right. These lock the base in position to the main display panel.



- 4 Carefully rotate the display into its normal standing position and peel back the film on the top about 2 inches down.



- 5 Push the lid into position taking care not to crease the edge of the paper insert when pushing down.



- 6 Your unit is ready for display!